

CS 352

Circuit & Packet Switching

Lecture 2

<http://www.cs.rutgers.edu/~sn624/352-S22>

Srinivas Narayana


Review of definitions

- **Endpoint or Host:** Machine running user application
- **Packet:** a unit of data transmission (ex: 1500 bytes)
- **Link:** a physical communication channel between two or more machines
- **Router:** A machine that processes packets moving them from one link to another towards a destination
- **Network:** Collection of interconnected machines
- **Address:** a unique name given to a machine (more later)


How do machines talk?

How do machines communicate?

- With 1s and 0s
 - Computers only deal with 1s and 0s
 - So do networks
- How do we transmit 1s and 0s in a network?



Physical transmission on a single link



Physical signaling (light, AC voltages, etc.) are often **analog**

Convert bits to signals through **modulation** of the physical characteristics of signals: **encoding**

Convert signals back to digital by **decoding** physical signals





Fig. 2-18. (a) A binary signal. (b) Amplitude modulation. (c) Frequency modulation. (d) Phase modulation.

Multi-link networks



- Need a way to move data across links
- We use the term **switching** to denote physically moving data from one link to another

Switching schemes

Host applications transfer data containing many **messages**.

(1) Circuit Switching

(2) Message Switching

(3) Packet Switching


Circuit switching

- Provides service by setting up the **full path of connected links** from the origin to the destination
- Example: Telephone network

Circuit switching

1. **Setup:** Control message sets up a path from origin to destination
2. Return signal informs source that data transmission may proceed
3. **Data transmission** begins
4. Entire path remains allocated to the transmission (whether used or not)
5. When transmission is complete, source releases the circuit

Circuit switching




Message switching

- Each message is addressed to a destination
- **Header:** metadata that denotes how to process a message
 - Typically includes a destination **address**
- The message “hops” from node to node through a network **while allocating only one link at a time**
 - Compare to circuit switching: all links reserved at the same time, regardless of use.
- Analogy: Postal service

Message switching

- When the entire message is received at a router, the next step and link in its journey are selected
- If this selected link is busy, the message waits in a **queue** until the link becomes free
- **Store and forward** switching
 - Router waits for all message bits to arrive on incoming link before sending the first bit on outgoing link
 - Alternative: **cut-through** switching sends bits as they arrive


Message Switching



Packet switching

- Messages are split into smaller pieces called **packets**
 - Packets have a maximum length
 - Packets are numbered and addressed
 - Packets are sent through the network one at a time
- **Pipelining**: different parts of a message concurrently transmitted over different links
 - Provides higher utilization of link resources

Packet switching



The Internet uses store-and-forward packet switching.

Comparisons across switching tech

- Circuit switching incurs an initial delay to set up the path
 - Packet (and message) switching can start transmitting data right away
- Packet switching doesn't reserve resources for the conversation
 - Circuit switching does. Needs **admission control**
 - Packet switching makes resource reservation decisions per packet
- Fewer or no guarantees → easier to build
 - Telephone networks are more reliable and harder to build

Comparisons across switching tech

(1) **Total Delay to transfer a message**

Short Bursty Messages:

Packet < Circuit

Long Continuous Messages:

Circuit < Packet

(2) Header overhead (what % of bits on the wire is metadata?)

Packet > Message

(assuming typical msgs larger than typical pkts)

Measuring Networks

Some definitions


- Packet size: length of a packet (bits or bytes), incl. header and data
- **Bandwidth**: For a single link, amount of data it can transmit per unit time (bits/second or Bytes/second or packets/second)
- **Propagation delay**: Time needed to move one bit across (second)
 - Imposed by the communication medium; depends on the link “length”
- **Transmission delay**: Time from first bit@sender to last bit@sender
 - Determined by link bandwidth and packet size
- **Queueing delay**: Time that a packet waits for transmission
 - Determined by contention for the link
- **Total packet delay**: time from first bit@sender to last bit@receiver
 - propagation delay + queueing delay + transmission delay for a single packet

An analogy: Conveyor belt



- Propagation delay = time for first box to travel the length of the belt
- Bandwidth = the number of boxes put on the belt per minute (“rate”)
- Suppose we have N boxes in one shipment
- Shipment transmission time = N / rate
 - The next box is put on the belt $(1/\text{rate})$ minutes after the last
- Total transfer time = transmission time + propagation delay

Visualizing the delays



Bandwidth and delay

- A small demo...


Protocols and Layering


Protocols: The “rules” of networking

- Protocols consist of two things
 - **Message format**
 - structure of messages exchanged with an endpoint
 - **Actions**
 - operations upon receiving, or not receiving, messages
- Example of a Zoom conversation:
 - Message format: English words and sentences
 - Actions: when a word is heard, say “yes”; when nothing is heard for more than 3 seconds, say “can you hear me?”

The protocols of the Internet

- Standardized by the Internet Engineering Task Force (IETF)
 - through RFCs (“Request For Comments”)
- Layering





Transport address (port) Ex: 64058
Network address (IP address) Ex: 192.168.1.4
Hardware address (MAC address) Ex: 00-15-C5-49-04-A9

With which app is this conversation associated?

Whose network am I attached to?

How do I identify my network interface (device)?

The Internet


Google's network

Application address (URL)
Ex: mail.google.com

Transport address (port)
Ex: 4096

Network address (IP address)
Ex: 10.1.1.104

Hardware address (MAC address)
Ex: 00-15-C5-49-04-A7



Software and hardware for networking
are arranged in layers.



Layering provides **modularity**







Each layer has a **distinct function**
& interacts with other layers through
well-defined **interfaces**.


Modularity through layering

Protocols “stacked” in
endpoint and router
software/hardware












Packet starts as an app "payload"



Packet takes on headers at each layer







Applications

Transport

Network

Link layer

Routers do not typically
have transport or app
functionality
(more on this later.)

Network

Link layer

Network

Link layer

Applications

Transport

Network

Link layer

Layering

- Network communication is very complex
- Layering simplifies understanding, testing, maintaining
- Easy to improve or replace protocol at one layer without affecting others

This course has layers

